

Labview Procedure using THUM OCX

Tested with Labview 8.6

1. Install THUMocx using the installer.
2. Launch Labview.
3. On the front panel of new vi:
 - a. add an active x container.
 - b. right click the container and select <insert active x object>
 - c. select <create control> and scroll down the list to <THUMcontrol.THUMocx>, press <ok>
 - d. then create the diagram.

It is far easier to show a picture of the diagram than to explain it in words so here is what the front panel and diagram should look like.

